Grandslam Entertainment Safety Rules for Inflatables

- 1. *Supervision by an adult trained attendant is required at all times.
- 2. The Operator/Attendant should make all riders aware of the rules posted on the inflatable.
- 3 Inflatable anchors MUST BE secured at all times.
- 4. Entry into the inflatable should be orderly and in a controlled manner.
- 5. Riders should be of similar age range, height, and weight. Do not put older children or adults with younger children. Consider renting an additional smaller unit for younger children and toddlers.
- 6. Persons with mental or physical impairment should not be allowed to use any of the inflatable devices without 1 on 1 direct contact.
- 7. NO: Riders under age of 3 years old.
- 8. NO: Shoes, eyeglasses, jewelry, or other sharp objects.
- 9. **NO:** Somersaults, diving, wrestling, rough play, or flips.
- 10. No: Food, drinks, gum, pets, or Silly String(Renter Responsible for full cost of replacement of unit if silly string gets on the unit)
- 11. Do not jump onto or off the ride.
- 12. Use of whistles or signaling devices is recommended.
- 13. Keep all patrons away from blowers at all times.
- 14. **DO NOT USE:** Immediately deflate the unit if wind conditions exceed 15 MPH or it rains.
- 15. Minimum number of adult operators on an Inflatable Slide is two (2)
- 16. Minimum number of adult operators on a Inflatable Bouncer is one (1)
- 17. Maximum weight per passenger on slide or bouncer is 250 lbs.

Rides with Climbs and Slides

- 1. Go down slide feet first only, one rider per lane at a time.
- 2. **NO:** climbing up the slide the wrong way.
- 3. **NO:** jumping onto the slide area.

Emergency Procedures

In the unlikely event of a severe Weather Alert, Power Failure, or a Medical Emergency:

- 1. Exit patrons in an orderly fashion away from the inflatable.
- 2. Turn off the blower and unplug the outlet.
- 3. Keep patrons and guests away from the inflatable.
- 4. Call the appropriate emergency responders if necessary.